

Firmware upgrade instruction

1. Connect the ZYX gyro to PC by ZYX USB adapter, select the correct COM port by hand, click "Connect ZYX", make sure it succeed.
2. Click "Open" to select and open the firmware in "upgrade firmware" file.
3. Keep the PC, USB adapter and ZYX gyro connecting. Power off ZYX gyro, press "SET" button of gyro and power on.
4. The red lamp is flashing, click "Upgrade" button to start upgrade, the ZYX gyro will restart after successful upgrade.
5. Please make sure the firmware is suitable for your gyro, otherwise the gyro will be damaged.
6. If the upgrade fails, redo the 3, 4 steps. If the ZYX does not work because of upgrade failure, select the correct COM port by hand, and operate from the 2 step.

